



INFERNO WHITE STICKER KIT

Installation Instructions

**KTM 125/200/250/390 DUKE
MODEL YEAR 2017+**

IMPORTANT

- Work slowly and by the installation instruction
- Bike has to be on a bike stand
- Don't use water. BP sticker kits have a special glue, so you can correct the stickers and re-apply
- If you need to reattach something do it with both hands and slowly
- After the sticker kit is completed, do not wash the bike for the next 24h
- Don't do the sticker installation on the sun.

WHAT DO YOU NEED?

- Bike cleaner and clean hands.
- Duct tape just to measure the stickers
- Heat gun (recommended not crucial)
- Micro fiber towel
- Screwdriver for the tank (only for Superduke)
- Beer or a two (one for you friend)







